

TOUCH

Panel global description

Zones | Pages

Zone selection (TOUCH 1024)

Page selection (TOUCH 512)

Tap to select zones/Pages individually
hold for 2 seconds to combine Zones

Tactile Wheel Picker & Dial

Active zone to choose a scene,
adjust colour temperature or
intensity (+/-) or speed (+/-)

On / Off

Tap to cancel wheel settings
Hold 3 seconds for Black Out

Scene Speed

Dial the wheel to adjust
scene playback speed (+/-)

Speed Mode Activation

Use the wheel to change the
current scene speed
(Active for 5 seconds)

Scene Mode Activation

Use the wheel to start or stop
the selected scene



Scenes

Pick a scene (1-8)

8 scenes per Zone or Page

Colour Wheel - RGB - WA

Pick RGB - Amber - White colour
for the selected zone

Colour Temperature - WA

Pick cool to warm white for the
selected zone

Dimmer Intensity

Dial the wheel to adjust
light intensity (+/-)

Dimmer Mode Activation

Use the wheel to adjust brightness
for the selected zone
(Active for 5 seconds)

Colour Mode Activation

Use the wheel to pick
RGB - Amber - White colour

Hold 3 seconds to enter
cool/warm white mode